Front TV Display Instructions

Display Power

- Press [ON] to turn the TV display on.

- Press [OFF] to turn the TV display off.

Video Source

- Press [HDMI] to use the HDMI input as the video source.
  - *Select the HDMI input when using the instructor station computer.*

- Press [VGA] to use the VGA input as the video source.
  - *Select the VGA input when connecting the VGA cable to your laptop or other computer. VGA cable is located directly behind the instructor station. You may need a suitable adapter to connect to the video output of your computer.*

Sound Source

- When [HDMI] is the selected video source, sound output to the TV is through the HDMI cable.

- When [VGA] is the selected video source, sound output to the TV is through the 1/8" stereo cable paired with the VGA cable.

Sound Volume

- Use the volume control buttons to increase or decrease television sound volume.
  - *Volume adjustment is **extremely gradual**. You will need to hold down the volume buttons for several seconds before a noticeable change will occur.*

- Use the [MUTE] button to instantly turn sound on or off.

Instructor Station Sound Source

By default, sound will play from the HDMI/front TV display speakers. To select a different sound output, click the menu in the top left corner and open *System Preferences*. From there, click the *Sound* icon and then the *Output* tab.

Select a device for sound output:

Name	Type
Internal Speakers	Built-in
V801	HDMI

Select a device for sound output:

Name	Type
Headphones	Headphone port
V801	HDMI

- For sound to the TV via the HDMI cable (such as when using the instructor station while [HDMI] is the selected video source), select **V801 | HDMI**.

- For sound to the TV via the 1/8" stereo jack (such as when using headphones or when using the instructor station while [VGA] is the selected video source), select **Headphones | Headphone port**.

For assistance, contact UVM Libraries Classroom Technology Services at (802) 656-8924.