

Job Hazard Analysis

JHA Number 0038-PPD-HVAC	Facility University of Vermont	Date Prepared 1/2/2020	Revision Date
Approved by		Analysis by WALKER, CHRISTOPHER	
Description Working Above Suspended Ceiling Tiles			
Smart Tabs			
Related Job Titles	Related Departments * CONTROLS * DAVIS CENTER ZONE * LIFE SAFETY SYSTEMS * MEDICAL COMPLEX ZONE * MEDPLEX PROJECT RENOVATIONS * PROJECT MANAGEMENT GROUP * PROJECTS ZONE * SOUTH ZONE * TRAINING & COMPLIANCE * TRINITY ZONE * UTILITIES ZONE	Related Locations	Related MSDS
Training Requirements			

Additional Description
This JHA applies to all staff going above Suspended Ceiling Tiles
Common sense should be applied when executing any job. We do our best to implement hazard control measures such as engineering controls, administrative controls and personal protective equipment. When the hazard is still present the use of certain PPE may be required for one or more steps but not all of the steps. However, it may be prudent to don all required PPE for the duration of the JHA.

Step/ Area	Task Step Description	Hazards	Control Measure	PPE Required
1	Always call TCO prior to going above any Suspended Ceiling Tile System (SCTS) in buildings built prior to 1980. TCO has (or can obtain) the information needed as to the hazards above SCTS.	Asbestos Silica Concrete Miscellaneous items	Calling TCO	
2	Going Above Suspended Ceiling Tile: *Lift tile straight up taking care not to tip it *Place over adjacent tile	Dust Respiratory Hazards Cuts, Scrapes Eye hazards	Don PPE prior to opening up ceiling area Proper ladder use	Safety glasses, UVM Issued; Gloves, leather ; Respirator cartridges, P100; Respirator, half-face

Prepared By: _____ **Date:** _____