Dry Food Dispenser Assembly Instructions for GAT 200/201/202/203 Model

+ Assembling

- 1. Carefully remove all the parts from the packaging
- 2. Place the stand in the tray holder by pressing firmly downwards
- 3. Place the containers in the stand

The dispenser is now ready for use!

+ Disassembly

- 1. Take the containers out of the stand
- 2. Remove the lids
- 3. Pull the tap out
- Remove the rubber blade by carefully pulling it through to the top

+ Cleaning

- Wash the parts in warm water with a little soap never use an abrasive sponge or cloth
- 2. Make sure that all parts are completely dry before reassembling
- Insert the rubber blade (Pay attention to "front" marked on the blade and the pin on the rear side of the blade)
- Insert the tap into the rubber blade, pushing it all the way through and turning it until you feel a click
- 5. Place the lids back on the containers



The Zevro™ Indispensable™ Countertop Dispenser is backed by our limited 90-day warranty against manufacturer defects. If your unit should fail due to a manufacturer defect within the warranty period, return it to Zevro in its original packaging along with the original receipt for a full refund or exchange. Only valid in the U.S.A.

ZEVRO

3720 West Touhy Avenue. Skokie, IL 60076 | Tel: 1 800 313 8588 | www.zevro.com

