

Job Hazard Analysis

JHA Number 0046-PPD-CARP	Facility University of Vermont	Date Prepared 9/17/2021	Revision Date
Approved by		Analysis by WALKER, CHRISTOPHER	
Description Air Conditioner Installation and Removal			
<i>Smart Tabs</i>			
Related Job Titles	Related Departments	Related Locations	Related MSDS
Training Requirements			

<i>Additional Description</i>
Air Conditioner Installation and Removal
<p>Whenever possible, this task should be completed in teams of two. Common sense should be applied when executing any job. We do our best to implement hazard control measures such as engineering controls, administrative controls, and personal protective equipment. When the hazard is still present the use of certain PPE may be required for one or more steps but not all the steps. However, it may be prudent to don all required PPE for the duration of the JHA.</p>

Step/ Area	Task Step Description	Hazards	Control Measure	PPE Required
1	Window Air Conditioner Unit Installation	Lead Paint/Pinch Hazard	Prior to install, open window sash and HEPA vacuum the window well/trough to clear it of possible paint chips. Check the floor under the window and vacuum any paint or debris. Wash hands after work is complete.	UVM Issued Safety glasses; Leather or Mechanix style gloves
2	Window Air Conditioner Unit Removal	Lead Paint/Pinch Hazard	Once the window unit is removed, HEPA vacuum the window well/trough to clear it of possible paint chips. Check the floor under the window and vacuum any paint or debris. Wash hands after work is complete.	UVM Issued Safety glasses; Leather or Mechanix style gloves

Prepared By: _____ **Date:** _____