

# SPATIAL MODELS FOR THE STATEWIDE EVALUATION OF TRANSIT-SUPPORTIVE ZONES

Nathan P. Belz, M.S., E.I., University of Vermont


Lisa Aultman-Hall, Ph.D., University of Vermont

Gopal R. Patil, Ph.D., Indian Institute of Technology Bombay




RESEARCH  
EDUCATION  
OUTREACH

UNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER



## What are the challenges of transit in rural states?

- Spatial Constraints
  - Long Travel Distances
  - Low Densities




## What needs to be done?

- Move beyond large-rural analysis for local services
- Define areas that are transit serviceable statewide
- Develop objective process to determine transit demand
- Determine demand potential and VMT reduction



## What has been done for spatial transit demand research?

- Quality of Transit Service
- Access and Coverage
- Density and Land Use



## What are the shortfalls of past spatial research?

- Zonal level and/or small extents with urban focus
- Assumptions of homogeneity within zones







Vermont E911 Database



Number of Dwelling Units for Multi-Family Structures



Employment Statistics by Land-Use Type



Trip Generation Rates by Land-Use Type



Hourly Distribution of Trips



Vermont Statewide-Travel Demand Model



# METHODS

## Transit- Supportive Zones

Introduction

Background


Data




Results

Conclusions

### STEP 1: Apply dwelling unit values to multi-family structure points



0 0.5 1 2 Miles




### E911 Points

- Single-Family Structures
- Multi-Family Structures
- Non-Residential Structures

RESEARCH  
EDUCATION  
OUTREACHUNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER

**STEP 1:** Apply dwelling unit values to multi-family structure points


**STEP 2:** Apply employment levels to each non-residence point



**STEP 1:** Apply dwelling unit values to multi-family structure points

**STEP 2:** Apply employment levels to each non-residence point

**STEP 3:** Apply trip generation rates to all points



***Demand Potential (DP)***





# METHODS

## Transit- Supportive Zones


[Introduction](#)[Background](#)[Data](#)[Results](#)[Conclusions](#)

**STEP 1:** Apply dwelling unit values to multi-family structure points

**STEP 2:** Apply employment levels to each non-residence point

**STEP 3:** Apply trip generation rates to all points

**STEP 4:** Divide demand potential for each point by the demand potential for a single-family home



*Equivalent Demand Potential (DP)*



# METHODS

## Transit- Supportive Zones

Introduction

Background


Data



Results



Conclusions

### STEP 5: Sum the EDP for each acre



**EXAMPLE: Montpelier, VT**


**EDP**



RESEARCH  
EDUCATION  
OUTREACH


UNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER

### STEP 5: Sum the EDP for each acre



**EXAMPLE: Montpelier, VT**

**EDP**



		1			1	1		
		1	1	1	1			
	1		3	1	1	1		
			5	4	3	3	1	
		1	2	7	3	1		1
	1	1	1	5	2	1		
	1	1	1	1	1	2		
	1	1		1	1			
				1				



# METHODS

## Transit- Supportive Zones

Introduction

Background

Data




Results

Conclusions



**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value



**EXAMPLE: Montpelier, VT**

**Neighborhood Measure**



RESEARCH  
EDUCATION  
OUTREACH

UNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER

# METHODS

## Transit- Supportive Zones

Introduction

Background

Data




Results

Conclusions


**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value



**EXAMPLE: Montpelier, VT**

**Neighborhood Measure**



	2	3	4	4	4	3	1	
1	2	7	8	9	6	5	2	
1	2	10	16	20	15	10	5	1
1	2	12	21	29	27	13	7	2
1	3	11	26	32	29	14	7	2
2	6	9	20	23	23	10	5	1
3	6	8	12	13	14	7	3	
2	4	5	6	6	7	4	2	
1	2	2	3	3	3	1		



RESEARCH  
EDUCATION  
OUTREACH

UNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER



# METHODS

## Transit- Supportive Zones

Introduction

Background

Data



Results

Conclusions

**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value

**STEP 7:** Determine the spatial grid  
Neighborhood Maximum value

	2	3	4	4	4	3	1	
1	2	7	8	9	6	5	2	
1	2	10	16	20	15	10	5	1
1	2	12	21	29	27	13	7	2
1	3	11	26	<b>32</b>	29	14	7	2
2	6	9	20	23	23	10	5	1
3	6	8	12	13	14	7	3	
2	4	5	6	6	7	4	2	
1	2	2	3	3	3	1		



# METHODS

## Transit- Supportive Zones

Introduction

Background

Data



Results

Conclusions

**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value

**STEP 7:** Determine the spatial grid  
Neighborhood Maximum value

2	7	8	9	9	9	6	5	2
2	10	16	20	20	20	15	10	5
2	10	21	29	29	29	27	13	7
2	12	26	32	32	32	29	14	7
6	12	26	32	32	32	29	14	7
6	11	26	32	32	32	19	14	7
6	9	29	23	23	23	23	10	5
6	8	12	13	14	14	14	7	3
4	5	6	6	7	7	7	4	2



**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value

**STEP 7:** Determine the spatial grid  
Neighborhood Maximum value

**STEP 8:** Identify local maximums

1/32	7/32	1/32
18/32	32/32	9/32
11/32	14/32	6/32




**STEP 5:** Sum the EDP for each acre

**STEP 6:** Calculate the spatial grid  
Neighborhood Measure value

**STEP 7:** Determine the spatial grid  
Neighborhood Maximum value


**STEP 8:** Identify local maximums

**STEP 9:** Apply service area to local maximum centroids  
and sum EDPs within service area




### Criteria to be a Transit-Supportive Zone


- Must have a local max as centroid
- $\Sigma$  EDP must be greater than or equal to seven at the central acre
- $\Sigma$  EDP must be greater than or equal to 3520 for the entire service zone



*Burlington, VT & Surrounding*



*Montpelier, VT*









## Transit-Supportive Demand Proportion

- Sum of EDP in the portion of each TSZ falling within the  $n^{\text{th}}$  TAZ (X)
- Sum of EDP in the  $n^{\text{th}}$  TAZ (Y)
- Divide (X) by (Y)
- Represents the proportion of trips within a TAZ that could *theoretically* be served by transit

$$TSDP = \frac{EDP_{TSZ}(n)}{EDP_{TAZ}(n)} = \frac{X}{Y}$$



## Transit-Supportive Demand Proportion



0 0.5 1 2 Miles



# METHODS

## Estimation of Potential Transit Demand

Introduction

Background

Data




Results

Conclusions



### Potential Transit Demand (Person Trips)

- Trip must originate in and be destined for a TSZ
- Gravity update of state model using TSDP as the “growth” factor
- Reduced by 7.6% for trips occurring outside of typical transit operation hours
- Subtracted existing transit trips




#### EXAMPLE: Montpelier, VT

##### Person Trips



##### Person Trips



RESEARCH  
EDUCATION  
OUTREACH

UNIVERSITY OF VERMONT  
TRANSPORTATION RESEARCH CENTER


## Estimation of VMT Reduction

- Divide person-trips ( $T$ ) by auto-occupancy for a given trip-purpose ( $P$ )
- Number of trips ( $A$ ) occurring between OD pairs
- Shortest network distance ( $B$ ) between OD pairs
- Number of trips ( $C$ ) occurring within TAZ
- Intrazonal trip length ( $D$ ) approximated as radius of a circle with area equivalent to TAZ area

$$AT_{ij} = \sum_p \left[ \sum_{ijp} \frac{TT_{ij}^{(p)}}{AO_p} \right] = \frac{T}{P}$$

$$R_{VMT} = \sum_{ij} (AT_{ij} * \text{Min}[DN_{ij}]) + \sum_i (AT_i * D_{TAZ})$$

$$= (A * B) + (C * D)$$





## % WITHIN TSZs BY REGION

	<i>MPO</i>	<i>Non-MPO</i>	<i>Vermont (Total)</i>
<b>Land Area</b>	6	0.6	0.9
<b>Residence Points</b>	37	12	17
<b>Employment Points</b>	66	33	39





TRIP PURPOSE	AUTO TRIPS	AUTO VMT (miles)	% “REDUCTION”	
			Trips	VMT
Home-Based Work	137,210	938,895	37	21
Home-Based Shopping	62,910	392,408	38	20
Home-Based School	4,964	25,443	38	19
Home-Based Other	133,599	601,829	34	16
Non-Home Based	194,161	635,924	64	33
<b>TOTAL</b>	<b>532,844</b>	<b>2,594,499</b>	<b>43</b>	<b>21</b>



## Transit-Supportive Zones

- Data and methodology used
- TSZs are spread throughout the state
- 1% of VT land area is transit-supportive

## Estimation of Demand

- 43% of all trips occur within or between TSZs
  - 86% Intercity
  - 14% Intracity
- Theoretically if all “potential” could be served
  - 21% statewide reduction in VMT





## Importance of disaggregate data

- Generally much more available for urban areas
- Illustrates application of E911
- Identifies need for similar data on national scale
- Application as data-driven decision tool

## TSZs and Potential Transit Demand

- Relatively large proportion of substitutable intercity trips
- Not just in the one Vermont MPO
- Unlikely *all* identified potential can be connected





## Spatial analysis is not stand-alone

- Supplementary material
  - Social equity and need
  - Energy efficiency and network walkability

## Indication of location and level of demand

- Increase transportation system efficiency
- Develop spatially-optimal fixed-route transit network
- Where to serve with fixed route or demand responsive



## Preliminary work


- Model transit networks
  - Spatially-optimal
  - Equitably-augmented
  - Socially-equitable
- Able to identify
  - Underserved locations
  - Over-served locations
  - Shortest-path discrepancies





## Preliminary work

- Model transit networks
  - Spatially-optimal
  - Equitably-augmented
  - Socially-equitable
- Able to identify
  - Underserved locations
  - Over-served locations
  - Shortest-path discrepancies





Funding provided by:

US Department of Transportation

Research and Innovative Technology Administration

Collaboration with:

Dr. Austin Troy

Assistant Professor, UVM RSENr

James Sullivan, P.E.

Research Engineer, UVM TRC

Andrew Weeks, P.E.

Research Engineer, UVM TRC



